

# L'AUTHENTIQUE

PAINTS & INTERIOR

## *High gloss lacquer water-based*

### **Already painted woods**

Always ensure a well-ventilated and heated room with paintwork. The ideal temperature for painting is 20°C. Do not paint in full sun or an area that is too cold or too damp. Cover floors and surrounding furniture with foil. Mask off any surrounding surfaces with appropriate masking tape. The surface must be clean, dry and free of grease. High Gloss Lacquer WV is suitable for interior woodwork. Use a suitable paint roller for a smooth result.

#### Necessities:

- Cover film
- Masking tape
- Bucket of water and a cloth
- Protective clothing
- St Marc or another degreaser
- Duster
- Paint tray
- Paint roller
- Stir stick
- Acrylic brush
- Sandpaper
- High gloss lacquer WV on color

1. Cover all surrounding surfaces with masking film
2. Mask off any surrounding surfaces with appropriate masking tape
3. Dust the surface
4. Degrease the surface with St. Marc or another suitable degreasing agent
5. Rinse the surface with clean water and let it dry thoroughly
6. Sand the surface and cut off loose particles
7. Does bare wood appear? Then paint these parts with a primer WV. Isn't bare wood coming out? Then proceed to step 13
8. After drying, sand the primer lightly.
9. Dust the surface
10. Fill any holes with a suitable filler
11. Sand this smooth after drying
12. Dust the surface
13. Paint the surface with the High Gloss Lacquer WV. Apply the edges with a lacquer brush and apply the large surfaces with a lacquer roller. Let the High Gloss Lacquer WV dry sufficiently, consult the label or the manual.
14. Remove splashes immediately with a cloth and water

# L'AUTHENTIQUE

---

## PAINTS & INTERIOR

15. Lightly sand the surface again
16. Dust the surface
17. Paint the surface with the High Gloss Lacquer WV. Apply the edges with a lacquer brush and apply the large surfaces with a lacquer roller.
18. Allow the High Gloss Lacquer to cure sufficiently before the surface can be polished.