

L'AUTHENTIQUE

PAINTS & INTERIOR

High gloss lacquer water-based

Untreated wood

Always ensure a well-ventilated and heated room with paintwork. The ideal temperature for painting is 20°C. Do not paint in full sun or an area that is too cold or too humid. Cover floors and surrounding furniture with foil. Mask off any surrounding surfaces with appropriate masking tape. The surface must be clean, dry and free of grease. High Gloss Lacquer WV is suitable for interior woodwork. Use a suitable paint roller for a smooth result.

Necessities:

- Cover film
- Masking tape
- Bucket of water and a cloth
- Protective clothing
- St Marc or another degreaser
- Duster
- Paint tray
- Paint roller
- Stir stick
- Acrylic brush
- Sandpaper
- Primer WV on color if desired
- High gloss lacquer WV on color

1. Cover all surrounding surfaces with masking film
2. Mask off any surrounding surfaces with appropriate masking tape
3. Dust the surface
4. Degrease the surface with St. Marc or another suitable degreasing agent
5. Rinse the surface with clean water and let it dry thoroughly
6. Prime the surface and allow to dry sufficiently, refer to the label or manual
7. Immediately remove splashes with a cloth and water
8. Sand the surface after drying
9. Dust the surface
10. Fill any holes with a suitable filler
11. Sand this smooth after drying
12. Dust the surface
13. Paint the surface with the High Gloss Lacquer WV. Apply the edges with a lacquer brush and apply the large surfaces with a lacquer roller. Let the High Gloss Lacquer WV dry sufficiently, consult the label or the manual.
14. Lightly sand the surface again

L'AUTHENTIQUE

PAINTS & INTERIOR

15. Dust the surface

16. Paint the surface with the High Gloss Lacquer WV. Apply the edges with a lacquer brush and apply the large surfaces with a lacquer roller. Allow the High Gloss Lacquer WV to harden sufficiently before the surface can be polished.