

# L'AUTHENTIQUE

PAINTS & INTERIOR

## *Metallic Wall paint*

### **Walls:**

#### **Newly plastered walls**

When painting, always ensure a well-ventilated and heated room. The ideal temperature for painting walls is 15°C. Do not paint in direct sunlight or an area that is too cold or too humid. Cover floors and surrounding furniture with foil. Cover any window frames, door posts, baseboards and sockets with suitable masking tape. The surface must be clean, dry and free of grease. Metallic Wall Paint gives a metallic gloss color effect. Newly plastered walls must be sufficiently dry before painting and always be primed with an opaque or transparent primer. Use a suitable roller to apply metallic wall paint. Order enough paint, never start a new packaging halfway through a surface.

### **Necessities:**

- Cover film
- Masking tape
- Bucket of water and a cloth
- Protective clothing
- St Marc or another degreaser
- Duster
- Paint tray
- Roller, possibly a stick that can be applied on the roller
- Stir stick
- A small acrylic brush for the edges
- Primer
- Metallic Wall paint

1. Cover all floors and furniture with foil
2. Cover any window frames, door frames, skirting boards and sockets with suitable masking tape
3. Dust the walls
4. Stir or shake the primer well
5. Treat the wall with a primer to release the suction
6. Allow the wall to dry sufficiently, consult the label or manual
7. Stir the Metallic Wall Paint well for the first coat and check the color before use
8. Carefully pour the paint into a suitable paint container
9. Immediately remove splashes with water and a cloth
10. Divide the wall into imaginary areas
11. Paint with a smaller brush along the taped edges first
12. Run the roller or brush through the paint, making sure that the paint is evenly distributed

# L'AUTHENTIQUE

---

## PAINTS & INTERIOR

on the roller or brush

13. Start painting and work from top to bottom, evenly distributing the paint
14. Avoid banding by overlapping the bands by 10 cm
15. Allow the wall to dry sufficiently, consult the label or manual
16. Stir the metallic wall paint well for the second coat
17. Paint the walls a second coat
18. Remove the masking tape immediately after painting the second layer