

# L'AUTHENTIQUE

PAINTS & INTERIOR

## *Matte Wall paint*

### **Walls:**

#### **Already painted walls**

When painting, always ensure a well-ventilated and heated room. The ideal temperature for painting walls is 15°C. Do not paint in direct sunlight or an area that is too cold or too humid. Cover floors and surrounding furniture with foil. Cover any window frames, door posts, baseboards and sockets with suitable masking tape. The surface must be clean, dry and free of grease. Matte wall paint gives an even color effect. Use a roller to set up the matte wall paint for a smooth result.

#### Necessities:

- Cover film
- Masking tape
- Bucket of water and a cloth
- Protective clothing
- St Marc or another degreaser
- Duster
- Paint tray
- Roller, possibly a stick that can be applied on the roller
- Stir stick
- A small acrylic brush for the edges
- Matte Wall paint

1. Cover all floors and furniture with foil
2. Cover any window frames, door frames, skirting boards and sockets with suitable masking tape
3. Dust the walls
4. Degrease the wall with St. Marc or another suitable degreasing product
5. Rinse the wall with clean water and let the wall dry thoroughly
6. Fill any holes or irregularities with a suitable filler and let it dry according to the instructions
7. Stir the paint well
8. Carefully pour the paint into a suitable paint container
9. Immediately remove splashes with water and a cloth
10. Divide the wall into imaginary areas
11. Paint with a smaller brush along the taped edges first
12. Run the roller or brush through the paint, making sure that the paint is evenly distributed on the roller or brush
13. Start painting and work from top to bottom, evenly distributing the paint

# L'AUTHENTIQUE

---

## PAINTS & INTERIOR

14. Avoid banding by overlapping the bands by 10 cm
15. Allow the wall to dry sufficiently, consult the label or manual
16. Paint the walls a second coat
17. Remove the masking tape immediately after painting the second layer