

L'AUTHENTIQUE

PAINTS & INTERIOR

Matt Wall paint

Walls:

Newly plastered walls

When painting, always ensure a well-ventilated and heated room. The ideal temperature for painting walls is 15°C. Do not paint in direct sunlight or an area that is too cold or too humid. Cover floors and surrounding furniture with foil. Cover any window frames, door posts, baseboards and sockets with suitable masking tape. The surface must be clean, dry and free of grease. Matt wall paint gives an even color effect. Newly plastered walls must be sufficiently dry before painting and always be primed with an opaque or transparent primer. Use a roller for a smooth result to apply matt wall paint.

Necessities:

- Cover film
- Masking tape
- Bucket of water and a cloth
- Protective clothing
- St Marc or another degreaser
- Duster
- Paint tray
- Roller, possibly a stick that can be applied on the roller
- Stir stick
- A smaller acrylic brush for the edges
- Primer
- Matt wall paint

1. Cover all floors and furniture with foil
2. Cover any window frames, doorposts, skirting boards and sockets with suitable masking tape
3. Dust the walls
4. Treat the wall with a primer to release the suction
5. Allow the wall to dry sufficiently, consult the label or manual
6. Stir the paint well
7. Carefully pour the paint into a suitable paint container
8. Immediately remove splashes with water and a cloth
9. Divide the wall into imaginary areas
10. Paint with a smaller brush along the taped edges first
11. Run the roller or brush through the paint, making sure that the paint is evenly distributed on the roller or brush
12. Start painting and work from top to bottom, evenly distributing the paint

L'AUTHENTIQUE

PAINTS & INTERIOR

13. Avoid banding by overlapping the bands by 10 cm
14. Let the wall dry sufficiently, consult the label or manual
15. Paint the walls a second coat
16. Remove the masking tape immediately after painting the second layer