

# L'AUTHENTIQUE

PAINTS & INTERIOR

## Waterproof Stucco

### Walls:

#### Already painted walls

When painting, always ensure a well-ventilated and heated room. The ideal temperature for painting walls is 15°C. Do not paint in direct sunlight or an area that is too cold or too humid. Cover floors and surrounding furniture with foil. Cover any window frames, doorposts, baseboards and sockets with suitable masking tape. The surface must be clean, dry and free of grease. Already painted walls do not need to be primed with a primer. Waterproof Stucco is a waterproof stucco that gives the surface a concrete-like appearance. The Waterproof Stucco primer should always be applied under the waterproof stucco. Let the primer dry for at least 6 hours and then plaster the wall with 2 layers of Concrete Look Stucco. Order enough product, never start a new packaging halfway through a surface.

### Necessities:

- Cover film
- Masking tape
- Bucket of water and a cloth
- Protective clothing
- St Marc or another degreaser
- Duster
- Paint tray
- Roller and possibly a stick for the roller
- 2 stir sticks
- Smaller brush for the edges
- Stucco trowel
- Waterproof Stucco Primer for 1 layer
- Waterproof Stucco in color for 2 layers

1. Cover all floors and furniture with foil
2. Cover any window frames, doorposts, skirting boards and sockets with suitable masking tape
3. Dust the walls
4. Degrease the wall with St. Marc or another suitable degreasing product
5. Rinse the wall with clean water and let the wall dry thoroughly
6. Fill in any holes or irregularities with a suitable filler and let it dry according to the instructions
7. Stir the primer well
8. Immediately remove splashes with water and a cloth
9. Carefully pour the primer into a suitable paint container

# L'AUTHENTIQUE

---

## PAINTS & INTERIOR

10. Divide the wall into imaginary areas
11. Paint with a smaller brush along the taped edges first
12. Run the roller or brush through the primer, making sure that the primer is evenly distributed over the roller or brush
13. Start painting and work from top to bottom, evenly distributing the paint
14. Avoid banding by overlapping the bands by 10 cm
15. Let the wall dry for at least 6 hours, consult the label or manual
16. Apply the first layer of Waterproof Stucco with a trowel
17. Let the plaster layer dry sufficiently, consult the label or the manual
18. Sand the surface lightly
19. Dust the surface
20. Apply the second layer of Waterproof Stucco with a trowel
21. Remove the masking tape immediately after plastering
22. Let the Waterproof Stucco coat dry completely
23. If desired, finish the surface with a sealer, let a sealer cure for at least 4 weeks.