

# L'AUTHENTIQUE

PAINTS & INTERIOR

## Waterproof Stucco

### Floor and stairs:

#### Already painted wood or concrete

When painting, always ensure a well-ventilated and heated room. The ideal temperature for painting a floor is 15°C. Do not paint in direct sunlight or an area that is too cold or too humid. Cover surrounding furniture with foil. Cover any baseboards and bottom of walls with suitable masking tape. The surface must be clean, dry and free of grease. The Waterproof Stucco Primer should always be applied under the Waterproof Stucco. For horizontal surfaces, let the first coat of primer dry for at least 12 hours and the second coat of primer to dry for at least 6 hours. Horizontal surfaces must always be painted afterwards with a 2-component paint. Order enough product, never start a new packaging halfway through a surface.

### Necessities:

- Cover film
- Masking tape
- Bucket of water and a cloth
- Cushion for under your knees
- Protective clothing
- St Marc or another degreaser
- Sandpaper grit 80 and 230
- Vacuum cleaner
- Paint tray
- Roller and possibly a stick for the roller
- 2 stir sticks
- Smaller brush for the edges
- Stucco trowel
- Enough Waterproof Stucco Primer white for 2 layers
- Waterproof Stucco in color for 2 layers
- 2 component paint for 3 layers

1. If necessary, cover the area with protective film
2. Mask skirting boards and the bottom of walls with suitable masking tape
3. Vacuum the surface carefully
4. Degrease the surface with St. Marc or another suitable degreasing product
5. Rinse the surface with clean water and let it dry thoroughly
6. Sand the surface with 80 grit sandpaper and make scratches, this will ensure adhesion.
7. Vacuum the surface carefully
8. Stir the Waterproof Stucco primer well

# L'AUTHENTIQUE

---

## PAINTS & INTERIOR

9. Carefully pour the primer into a suitable paint container
10. Paint with a smaller brush first along the baseboards or walls
11. Run the roller or brush through the Waterproof Stucco primer and make sure that the primer is evenly distributed over the roller or brush
12. Start painting and spread the primer well
13. Let the first coat of primer dry for at least 12 hours, consult the label or manual
14. Then put on the second coat of primer and let it dry for at least 6 hours
15. Apply the first layer of Waterproof Stucco with a trowel and let it dry sufficiently
16. Sand the surface carefully
17. Scrape the second layer of Waterproof Stucco on
18. Remove the masking tape immediately after plastering
19. Finish horizontal surfaces with at least 3 layers of 2-component paint, consult the label or manual. Sand the 2 component layers in the meantime with sandpaper with grit 230.