

L'AUTHENTIQUE

PAINTS & INTERIOR

Waterproof Stucco

Floor and stairs:

Unpainted wood or concrete

When painting, always ensure a well-ventilated and heated room. The ideal temperature for painting a floor is 15°C. Do not paint in direct sunlight or an area that is too cold or too humid. Cover surrounding furniture with foil. Cover any baseboards and bottom of walls with suitable masking tape. The surface must be clean, dry and free of grease. The Waterproof Stucco Primer should always be applied under Waterproof Stucco. For horizontal surfaces, let the first coat of primer dry for at least 12 hours and the second coat of primer to dry for at least 6 hours. Horizontal surfaces must always be painted afterwards with a 2-component paint. Order enough product, never start a new packaging halfway through a surface.

Necessities:

- Cover film
- Masking tape
- Bucket of water and a cloth
- Cushion for under your knees
- Protective clothing
- St Marc or another degreaser
- Sandpaper grit 80 and 230
- Vacuum cleaner
- Paint tray
- Roller and possibly a stick for the roller
- 2 stir sticks
- Smaller brush for the edges
- Stucco trowel
- Primer transparent
- Enough Waterproof Stucco Primer white for 2 layers
- Waterproof Stucco in color for 2 layers
- 2 component paint for 3 layers

1. If necessary, cover the area with protective film
2. Mask skirting boards and the bottom of walls with suitable masking tape
3. Vacuum the surface carefully
4. Degrease the surface with St. Marc or another suitable degreasing product
5. Rinse the surface with clean water and let it dry thoroughly
6. Sand the surface with 80 grit sandpaper and make scratches, this will ensure adhesion.
7. Vacuum the surface carefully

L'AUTHENTIQUE

PAINTS & INTERIOR

8. Treat the surface with a transparent primer and allow to dry sufficiently
9. Stir the Waterproof Stucco primer well
10. Carefully pour the primer into a suitable paint container
11. First paint along the baseboards or walls with a smaller brush
12. Run the roller or brush through the Waterproof Stucco primer and make sure that the primer is evenly distributed over the roller or brush
13. Start painting and spread the primer well
14. Let the first coat of primer dry for at least 12 hours, consult the label or manual
15. Then put on the second coat of primer and let it dry for at least 6 hours
16. Apply the first layer of Waterproof Stucco with a trowel and let it dry sufficiently
17. Sand the surface carefully
18. Scrape the second layer of Waterproof Stucco
19. Remove the masking tape immediately after plastering
20. Finish horizontal surfaces with at least 3 layers of 2-component paint, consult the label or manual. Sand the 2 component layers in the meantime with sandpaper with grit 230.