

L'AUTHENTIQUE

PAINTS & INTERIOR

Waterproof Stucco

Walls:

Unpainted walls

When painting, always ensure a well-ventilated and heated room. The ideal temperature for painting walls is 15°C. Do not paint in direct sunlight or an area that is too cold or too humid. Cover floors and surrounding furniture with foil. Cover any window frames, door posts, baseboards and sockets with suitable masking tape. The surface must be clean, dry and free of grease. Already painted walls do not need to be primed with a primer. Waterproof Stucco is a waterproof stucco that gives the surface a concrete-like appearance. The Waterproof Stucco Primer should always be placed under the waterproof stucco. Let the primer dry for at least 6 hours and then plaster the wall with 2 coats of Waterproof Stucco. Always finish walls in bathrooms and kitchens with a 2-component lacquer. If desired, other walls can be finished with a sealer to make them washable. Order enough product, never start a new packaging halfway through a surface.

Necessities:

- Cover film
- Masking tape
- Bucket of water and a cloth
- Protective clothing
- St Marc or another degreaser
- Duster
- Paint tray
- Roller and possibly a stick for the roller
- 2 stir sticks
- Smaller brush for the edges
- Primer transparent
- Stucco trowel
- Waterproof Stucco Primer for 1 layer
- Waterproof Stucco in color for 2 layers
- Sealer or 2-component paint if desired

1. Cover all floors and furniture with foil
2. Cover any window frames, door frames, skirting boards and sockets with suitable masking tape
3. Dust the walls
4. Degrease the wall with St. Marc or another suitable degreasing product
5. Rinse the wall with clean water and let the wall dry thoroughly
6. Apply the transparent primer and let it dry sufficiently

L'AUTHENTIQUE

PAINTS & INTERIOR

7. Fill any holes or irregularities with a suitable filler and let it dry according to the instructions
8. Stir the primer well
9. Immediately remove splashes with water and a cloth
10. Carefully pour the Waterproof Stucco primer into a suitable paint container
11. Divide the wall into imaginary planes
12. Paint with a smaller brush along the taped edge first
13. Run the roller or brush through the primer, making sure that the primer is evenly distributed over the roller or brush
14. Start painting and work from top to bottom, evenly distributing the paint
15. Avoid strip formation by overlapping the strips by 10 cm
16. Let the wall dry for at least 6 hours, consult the label or manual
17. Apply the first layer of Waterproof Stucco with a trowel
18. Let the plaster layer dry sufficiently, consult the label or manual
19. Sand the surface lightly
20. Dust the surface
21. Scrap the second layer of Waterproof Stucco with a trowel
22. Remove the masking tape immediately after plastering
23. Let the Waterproof Stucco coat dry completely
24. If desired, finish the surface with 3 layers of sealer or 2-component lacquer, let a sealer cure for at least 4 weeks.